

























61821

PART	QTY	DESCRIPTION	NAME
A	4 PCS		Panel A
B	4 PCS		Panel B
C	4 PCS		Beam
D	4 PCS		Canopy Spoke
E	4 PCS		Canopy Frame
F	8 PCS		Track Tube
G	4 PCS		Short Canopy Spoke
H	1 PC		Lower Canopy Hub
I	4 PCS		Corner Connector
J	1 PC		Upper Canopy Spoke
K	24 PCS		M6X28 Bolt & Nut
L	12 PCS		M6X35 Bolt & Nut
M	4 PCS		M6X16 Bolt
N	4 PCS		M6X10 Bolt & Nut

O	1 PC		Small Fabric Cover
P	1 PC		Large Fabric Cover
Q	4 PCS		Netting
R	48 PCS		Plastic Ring
S	4 PCS		Corner Shelf
T	1 PC		Top Finial
U	4 PCS		Corner Finial
V	16PCS		Ground Spike
W	1 PC		Hanging lantern

Step 1: Fix the Panel (A) onto the Panel (B) by using M6X35 Bolts & Nuts (L). Repeat for the remaining Panels (A) and Panels (B) 3 times. See the Figure 1.

Step 2: Fix the 4 Corner Connectors (I) onto the top 4 corners of the connected Panels (A + B) by using M6X28 Bolts & Nuts (K). See the Figure 2.



Step 3: Line up the bolt holes on the two ends of the Beam (C) with the corresponding bolt holes on the side tubes of the Panel (A) and the Panel (B). Screw M6X28 Bolts & Nuts (K) on. Repeat for the remaining Beams (C), Panels (A) and Panels (B) 3 times. See the Figure 3.




Fig. 3

Step 4: Insert the 4 Canopy Spokes (D) into the 4 long tubes of the Lower Canopy Hub (H). Insert the 4 Canopy Frames (E) into the 4 short tubes of the Lower Canopy Hub (H). Make sure all snap buttons are in place. See the Figure 4.




Fig.4

Step 5: Place the Large Fabric Cover (P) on the top frames formed in **Step 4**. But do not tighten it in place. See the Figure 5.




Fig.5

Step 6: Insert 3 Short Canopy Spokes (G) into the Upper Canopy Hub (J) first. See the Figure 6. Then install the Small Fabric Cover (O) on the 3 Short Canopy Spokes (G) and pull the 3 corresponding pouches of the Small Fabric Cover (O) onto the ends of the 3 Short Canopy Spokes (G). See the Figure 7. Pull the remaining pouch of the Small Fabric Cover (O) onto the end of the remaining Short Canopy Spoke (G). See the Figure 8. Then insert the remaining Short Canopy Spoke (G) into the Upper Canopy Hub (J). See the Figure 9. Make sure all snap buttons are in place. Screw the Top Finial (T) on the Upper Canopy Hub (J). See the Figure 10.




Fig.6




Fig.7




Fig.8




Fig.10






Fig.9


Step 7: Insert the tubes of the 4 Short Canopy Spokes (G) into the tubes of the 4 Canopy Spokes (D). Make sure all snap buttons are in place. See the Figure 11.




Step 8: Place the roof structure formed in **Step 7** on top of panel structure formed in **Step 3**. Insert the 4 Canopy Spokes (D) into the 4 Corner Connectors (I). Make sure all snap buttons are in place. See the Figure 12. Fix the metal pieces on the ends of the 4 Canopy Frames (E) onto the 4 Beams (C) by using M6X16 Bolts (M). See the Figure 13. Place the Corner Shelves (S) on the connected Panels (A + B). See the Figure 14.




Step 9: Insert the end of the Track Tube (F) into the Corner Connector (I). See the Figure 15. Insert the other end of the Track Tube (F) into the bracket on the end of the Canopy Frame (E) and fix them together by using M6X10 Bolts & Nuts (N). Repeat for the remaining Track Tubes (F) 7 times. See the Figure 16.



Step 10: Put up the Nettings (Q) onto the Track Tubes (F) by using the Plastic Rings (R). Hang the fabric buckles in the middle of the Nettings (Q) onto the bolts of the Corner Connectors (I). See the figure 17.



Step 11: Pull the Large Fabric Cover (P) onto the Corner Connectors (I). Attach all the Velcro of the Large Fabric Cover (P) on the top frames and the top bars of the Panels (A & B). See the Figure 18. Screw the 4 Corner Finials (U) onto the 4 Corner Connectors (I). See the Figure 19. Pound the Ground Spikes (V) on the ground through the holes on the flat bars on the bottom of the Panels (A) and the Panels (B). See the Figure 20.



Step 12: Hanging on the lantern(w) to the hook under part “H” by the “S” shape hook on the chain. See the Fig 21




Fig. 21




Fig. 22

Instruction of the Hanging Lantern (see the Fig. 22):

Step1: To loose the bottom plate.

Step2: To fix the candle on the nail which in middle of the plate. Lighten on.

Step3: Put back the bottom plate with the candle.

Step4: Fix with the frame.